

TECHNICAL INSTRUCTION

Software update – CM/CB-E 3.0



Description

The technical instruction describes the step by step process conduct the software update on the controllers CM-E 3.0 and CM-E 3.0.



Required	Software: Smart Service-DA/CMD, Network cable / patch cable RJ45
----------	--

Step 1	Open the network and Internet settings on the laptop. (Important!!
·	Network connection from the laptop to port x25 must be available).
	\rightarrow Open <u>Ethernet</u>
	→ Open <u>Network and Sharing Centre.</u>
	\rightarrow Open <u>unidentified network Ethernet</u> .
	\rightarrow Open <u>Properties</u>
	If you are prompted for a password, log in with the user login. → Select Internet Protocol Version 4 (TCP/IPv4).

Step 2	\rightarrow Open <u>Properties</u> and select Use the following IP address:
	IP Address : 192.168.5.100
	Subnatmask : 255.255.255.0
	Gateway : 192.168.5.10
	\rightarrow Confirm with <u>OK</u>

Step 3	Return to Smart Service and select Options in the header
	\rightarrow Select <u>Control (Congrav, ISC)</u>
	→ Select Congrav CM-E, CB-E, CB-S (BT field bus)
	→ Select Protocol and select Ethernet Open Modbus TCP
	ightarrow Pop-up window opens with selection (Select Feeder)

Step 4	\rightarrow Select scale 1. Default IP address 192.168.5.251. Confirm with Connect.
	\rightarrow Select <u>Feeder 1</u> and confirm with double click
	→ Pop-up window opens - Select <u>Print button</u>
	ightarrow Pop-up window opens for entering the order number, etc. enter data and
	confirm with <u>OK</u>
	\rightarrow Print opens, select printer and PDF printer, confirm with <u>OK</u> , save PDF
	Feeder protocol with all parameters is now saved.



Step 5	 Return to Smart Service and select <u>Back-up</u> → Select <u>Load program CM/CB 3.0</u> → Select <u>Connect to Congrav.</u> When communication is active, the control window turns green → Select the Backup>PC button → Save the backup on the laptop.
Step 6	 → Select <u>directory of program</u> → Select the file path with the <u>ZIP file of the software</u> (Zip file must not be unpacked) → Select <u>Zip File</u> in the right window
	Select Start Update
Step 7	 A pop-up window with <u>Progress</u> opens. (Loading may take a few minutes) → The pop-up window <u>Program loaded successfully</u> opens. → Confirm with <u>OK.</u> → Execute PLC update (this can take up to 10min, needed from V4.80)
Step 8	 After the restart, perform a network reset. (After the network reset, the controller needs approx. 1 ½ minutes for the restart). → Return created backup, select "Restore data > CM/CB", select Back up and confirm with "OK". → Check back-up data. → If back-up is not available with feeder protocol PDF, enter the parameters with Smart Service.

If you have any questions, contact the hotline: +49 203/9984299